



INSTRUCTION MANUAL

PORTABLE
SCREW COMPRESSOR

FAC-75P
FAC-75PC
FAC-75B
FAC-75BC

Please be sure to read this manual
before using this machine.

Preface

Thank you for having selected our "FSCURTIS" product.

- ◆ This manual explains about the proper operation and daily inspection and maintenance of this machine.
- ◆ In order to use a machine safely, people with sufficient knowledge and sufficient technology need to deal with it.
- ◆ Before operating the unit, read the manual carefully, fully understand its operation and maintenance requirement. Maintain "SAFETY OPERATION AND PROPER MAINTENANCE OF THE UNIT".

Be sure to follow safety warnings and cautions given in the manual. Unsafe operation could cause serious injury or death.

- ◆ For details of handling, maintenance and safety of the engine, see the Engine Operation Manual.
- ◆ Keep the manual available at all times for the operator or safety supervisor.
- ◆ If the manual is lost or damaged, place an order with your dealer for another copy.
- ◆ Be sure that the manual is included with the unit when it is handed over to another user.
- ◆ There may be some inconsistency in detail between the manual and the actual machine due to improvements of the machine. Ask your dealer if you have any questions or problems.
- ◆ If you have any questions about the unit, please inform us the model and serial number. A plate stamped with the model and serial number is attached to side of the unit.

PORTABLE COMPRESSOR	
MODEL	<input type="text"/>
SER. NO.	<input type="text"/>
NORMAL OPERATING PRESSURE	<input type="text"/> MPa
NET DRY MASS	<input type="text"/> kg
OPERATING MASS	<input type="text"/> kg
 MADE IN JAPAN	

A090188

- ◆ Each illustrated figure (Fig.) has a number of 7 digits (for instance, A090188) at the right bottom. This number is not a part number, but it is used only for our reference number.


Table of Contents

1. Safety	1-1
1.1 Caution before Operation	1-2
1.2 Caution during Operation	1-5
1.3 Caution during Inspection and Maintenance	1-7
1.4 Safety Warning Labels	1-10
2. Part Names	2-1
2.1 Internal Components and Part Names	2-1
3. Installation	3-1
3.1 Transportation	3-1
3.2 Towing the Unit	3-2
3.3 Installation	3-3
4. Operation	4-1
4.1 Instrument Panel	4-1
4.2 Lubricating oil · Coolant · Fuel	4-4
4.3 Check before Starting Unit	4-6
4.4 Operation	4-10
4.5 Stopping	4-14
4.6 Operation of after cooler type	4-15
4.7 Volumetric Control System	4-16
5. Periodic Inspection/Maintenance	5-1
5.1 Important Items as Periodic Inspection and Maintenance or after Maintenance	5-1
5.2 Daily Inspection and Operation Log	5-2
5.3 Inspection on Separator Receiver Tank	5-2
5.4 Periodic Inspection List	5-3
5.5 Periodic Replacement of Parts	5-5
5.6 Maintenance Items	5-6
6. Maintenance	6-1
6.1 Maintenance of Battery	6-1
6.2 Troubleshooting	6-3
7. Storage of the Unit	7-1
7.1 Preparation for Long-term Storage	7-1
8. Specifications	8-1
8.1 Specifications	8-1
8.2 Outline drawing	8-2
9. Wiring Diagram	9-1
10. Piping Diagram	10-1

1.Safety

This manual explains and illustrates general requirements for safety.

Read all safety requirements carefully and fully understand the contents before starting the machine.

For your better recognition, according to the degree of potential danger, safety messages are classified into three hierarchical categories, namely, , , and  with a caution symbol  – attached to each message.

When one of these messages is shown, please take preventive measures and carry out “SAFETY OPERATION AND PROPER MAINTENANCE OF THE UNIT”.



DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations.



WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



IMPORTANT indicates important caution messages for the performance or durability of the unit.

Follow warnings mentioned in this manual. This manual does not describe all safety items. We, therefore, advise you to pay special attention to all items (even though they may not be described in the manual) for your safety.


1.Safety

1.1 Caution before Operation


DANGER

Compressed air is prohibited to be used for human respiration

- Compressed air by this unit contains poisonous materials. Absorption of the compressed air can cause serious injury. Never provide this compressed air for human respiration.
- This unit is not designed to be used for working chambers pressurized by compressed air such as respiratory air provided to persons working inside wells and tunnels such as pneumatic engineering method and pneumatic caisson method. Should this unit stop operation due to trouble, it can cause death and serious injury to the working persons. Refrain from using the compressed air for such pneumatic engineering method or pneumatic caisson method.



TR0201-1




A080001

WARNING

Follow the safety instructions

- Read each instruction plate which is displayed in the manual or on the unit carefully, understand its content and follow the indications thereof.
- Keep the Safety Warning labels clean. When they are damaged or missing, apply new ones.
- Do not modify the machine without prior approval. The safety may be compromised, functions may be deteriorated, or machine life may be shortened.
- Never use the unit for the purpose of compression of gases other than air, or as a vacuum pump. Otherwise, serious accidents may occur.




TR0086

WARNING

Ventilation

- Exhaust gas from the engine is poisonous, and could cause death when inhaled. Avoid using the machine in an insufficiently ventilated building or tunnel.



PC002

1.Safety

WARNING

- Keep flames away from battery.
- Battery may generate hydrogen gas and may explode.
- Battery electrolyte is dilute sulfuric acid.
In case of mishandling, it could cause skin burning.
- When you deal with a battery, please be sure to wear protection implements, such as protection glasses and a glove.
- Dispose of battery, observing local regulations.

Handling battery



D004




TR0093

WARNING

Cautions of hose attachment and removal

- Piping or the hose from this machine service valve should use what can be borne enough for the discharge pressure of this machine.
- Please connect piping or a hose to this machine service valve firmly before operation and during operation. If the connection part is loosening, there is a possibility of piping or a hose separating and getting seriously injured.
- Please remove after closing a service valve and extracting pressure remained, in case piping or a hose is removed. If pressure remained should remain, a near thing blows away or there is a possibility of a hose whipping, causing a phenomenon and getting seriously injured.
- In order to use it safely, please read the handling of the work tools often used.



TR0088



TR0303A

WARNING

Safety outfit

- When handling machine, do not wear;
 - Loose clothes
 - Clothes with unbuttoned sleeves
 - Hanging tie or scarf
 - Accessories such as dangling jewelry
- Such outfit could be caught in the machine or dragged in the rotating portion of the machine, and this could cause a serious injury.



TR0084

1.Safety

WARNING

Maintain both physical and mental health

- Do not operate the machine when you are tired or drunk or under the influence of drugs. Otherwise, a hasty conclusion or careless handling may cause unexpected injury or accident.
Manage your physical and mental health and be cautious in handling the machine.

CAUTION

- Please wear protection implements, such as a helmet, protection glasses, earplugs, safety shoes, a glove, and a protection-against-dust mask, according to the contents of work for safety.

Protection equipments



TR0085

CAUTION

- Have first-aid boxes and fire extinguishers near the unit ready for emergency situations such as injuries and a fire.
- It is advisable to have a list of phone numbers of doctors, ambulance and the fire department available in case of emergency.

Safety fittings



TR0096

CAUTION

Safety around the machine

- Such things as unnecessary equipment and tools, cables, hoods, covers and pieces of wood which are a hindrance to the job, have to be cleaned and removed. This is because operators and/or personnel nearby may stumble on them and may be injured.
- Place safety enclosures at the entrance of and around working site to prevent children or outside people from entering the site.


1.Safety

1.2 Caution during Operation

WARNING

Do not replenish compressor oil during operation

- Do not, under any circumstance, open the oil filler cap of separator receiver tank while running or immediately after stopping operation.
It is very dangerous because the oil filler cap could be blown off and high temperature compressed air and oil could jet out from the filler port, and cause serious injury.



WARNING

Draining during operation prohibited


- Do not, under any circumstance, open the portions below during operation:
 - Separator receiver tank drain valve
 - Coolant drain valve and plug
 - Engine oil drain valve
 - Oil cooler drain valve



WARNING

Never direct the compressed air to people and foods

- Never blow compressed air directly at people.
Scattered impurities, dust, or foreign objects in the compressed air may cause skin and eyes to be seriously injured.
- Blowing compressed air on food is prohibited.



WARNING

Hands off from rotating parts and belts


- Keep hands off from the rotating portion or belts while running.
It could cause serious injuries if hands should be caught in.



CAUTION

Do not remove radiator cap during operation

- Do not, under any circumstance, open the radiator cap while running or immediately after stopping operation. Otherwise high temperature steam jets out and this could cause scalding.




1.Safety

CAUTION

Operation with compressed air supply port opened is prohibited

- Do not operate the machine with service valves and relief valve open unless air hoses and/or pipes are connected. High-pressurized air blows out and its air pressure could cause injury to the people nearby.
- When the machine has to be unavoidably temporarily operated with its port open, be sure to mount a silencer to reduce noise and wear protective materials such as earplugs to prevent damage to hearing.




D003

CAUTION

Do not touch hot parts

- Never work nearby hot portions of the machine while it is running.
- Do not touch hot portions of the machine while inspecting the machine when running.
- Such parts as engine, exhaust manifold, exhaust pipe, muffler, radiator, oil cooler, compressor, piping, separator receiver tank, and discharging pipe are especially hot, so never touch those parts, because it could cause serious burns.
- Compressor oil, coolant water, and engine oil are also very hot and dangerous to touch. Avoid checking or refilling them while the unit is running.



H990432

CAUTION

Fire prevention

- Do not, under any circumstance, bring lit cigarettes or matches near such oils as engine oil and compressor oil, etc. They are extremely flammable and dangerous, so be careful when handling.
- Refilling oils should be done in an outdoor well-ventilated place.
- Refuel after stopping the engine, and never leave the fuel nearby the machine. Do not spill. It may cause a fire. When it is spilt, wipe it up completely.
- Do not fill fuel oil up to the cap lever. When fuel tank is filled up to the cap level, fuel oil will be overfilled due to volume expansion caused by rise of ambient temperature. Further, fuel will be possibly spilled from fuel tank due to vibration caused during movement and/or transportation of machine.
- Such parts as muffler and exhaust pipe can be extremely hot. Remove twigs, dried leaves, dried grass and waste paper, etc. from the exhaust outlet of the muffler.
- Keep a fire extinguisher available by the machine in case of a fire.



D004



H990433


1.Safety

1.3 Caution during Inspection and Maintenance

WARNING

Hang a "Now Checking and under Maintenance" tag


- Remove the starter key from the starter switch before starting inspection, and hang up a "Now Checking and under Maintenance" tag where it can be easily seen. The checker must keep the key during checking and maintenance.
- Remove the negative (-) side cable from the battery. If the above procedure is neglected, and another person starts operating the machine during check or maintenance, it could cause serious injury.



WARNING

Refilling of compressor oil


- When you refill the separator receiver tank with compressor oil, stop the engine, and make sure that the pressure gauge indicates 0MPa and there is no residual pressure in it, and then gradually loosen the oil filler cap for refilling oil.
- Note residual pressure in the separator receiver tank could force both extremely hot compressed air and oil to jet out and you may be scalded or seriously injured.



WARNING

Be careful of high-pressurized air blowout


- After stopping the engine, make sure that pressure gauge indicates 0MPa. Even when the gauge shows 0MPa, open a service valve and further do not fail to make sure that there is no residual pressure in the air piping. Then start such a job as repair and maintenance.
- Residual air under pressure will blow off and severely injure operator.



WARNING

Draining separator receiver tank

- After stopping the engine, confirm that the pressure gauge indicates 0MPa and there is no residual pressure in it, then open the drain valve gradually to drain the compressor oil.
- Note residual pressure in the separator receiver tank could force both extremely hot compressed air and oil to jet out and you may be scalded or seriously injured.



1.Safety

WARNING

- Be sure to stop the engine and remove the starter key whenever the tension of the fan belt is to be adjusted.
- Remove the negative (-) side cable from the battery.
- If the machine is running, it might catch the operator's hand into the fan belts, and this could cause a serious injury.

Adjusting tension of fan belt




TR0304

WARNING

- Be sure to stop the engine and remove the starter key whenever check or maintenance work is carried out near the cooling fan.
- If the cooling fan is rotating, it may catch the operator or part of his body into the fan, and it could cause a serious injury.

Hands off from cooling fan



W009

WARNING

- When cleaning dust accumulated in such devices as the air-filter, by blowing compressed air, wear safety glasses, etc. to protect your eyes.

Cleaning by air-blow




M003

CAUTION

- It is recommended to use a lamp with safety guard fitted where the site is dark.
Operating the machine gropingly or by relying on one's intuition could cause unexpected accidents.
- Any lamps without safety guard are not recommended since they can be broken and they could ignite flammables such as fuel, etc.

Lighting apparatus



TR0206

1.Safety

CAUTION

Opening coolant water drain valve cap


- Be sure to stop the engine, and let the coolant water sufficiently cool down before draining it.
- If the drain valve is opened before the coolant water is cooled enough, hot water could jet out, and it could cause scalding.



CAUTION

Refilling or draining of engine oil

- After stopping the engine, wait for 10 to 20 minutes until the engine oil cools off. Then check the level of the engine oil, or refill or drain the oil.
- Engine oil is very hot and highly pressurized during or just after the operation. Hot oil could blow out of the tank and can cause scalding.



CAUTION

Fear of fire

- Be sure to perform the periodical check of compressor oil and oil separator.
- Neglecting checks could cause overheat of the oil, resulting in a fire.



CAUTION

Disposal of waste liquid, etc.

- Waste liquid from the machine contains harmful material. Do not discharge it onto the ground or into the river, lake or sea. Such material will contaminate the environment.
- Be sure to use a container to hold the waste liquid from the machine.
- Be sure to follow the designated regulations when disposing of oil, fuel, coolant (antifreeze), filter, battery or other harmful materials.



1.Safety

1.4 Safety Warning Labels

Following labels are attached to the machine.


Keep them clean at all times. If they are damaged or missing, immediately place an order with your nearest dealer for replacement. Part numbers are indicated on the lower right corner of the label.

Adhere a new one to the original location.

<p>1</p> <p>▲ DANGER</p>  <p>DO NOT BREATHE COMPRESSED AIR</p> <p>Do not use this compressed air for breathing air because it can cause fatal accidents. Never breathe it.</p> <p>39176 73600</p>	<p>2</p> <p>▲ WARNING</p>  <p>BEWARE OF EXHAUST GASES</p> <p>When you operate machine INDOORS or in TUNNEL, provide good ventilation. Poor ventilation can cause fatal accident.</p> <p>39176 73300</p>	<p>3</p> <p>▲ WARNING</p>  <p>BEWARE OF RESIDUAL PRESSURE</p> <p>Release residual pressure inside pipings and hoses and then disconnect them. Disconnection with residual pressure still left can cause serious injury.</p> <p>39176 73400</p>	<p>4</p> <p>▲ CAUTION</p>  <p>PREVENT BURNING ACCIDENT</p> <p>Do not open radiator cap while it is still hot.</p> <p>39176 69600</p>	<p>5</p> <p>▲ CAUTION</p>  <p>PREVENT BURNING ACCIDENT</p> <p>When work is required near hot parts, wait for the parts to cool down fully before starting work.</p> <p>39176 69500</p>
<p>6</p> <p>▲ WARNING</p>  <p>BEWARE OF HIGH PRESSURE AIR BLOW OUT</p> <p>Oil supply and/or maintenance jobs with residual pressure left in tank are very dangerous. So release the residual pressure first.</p> <p>39176 69800</p>	<p>7</p> <p>▲ CAUTION</p>  <p>PREVENT FIRE ACCIDENT</p> <p>Periodically check compressor oil and oil separator surely. Failure of this fire accident.</p> <p>39176 69700</p>	<p>8</p> <p>▲ WARNING</p>  <p>BEWARE OF ENTANGLEMENT</p> <p>Keep your hands AWAY from fan during operation. Entanglement in the fan can cause serious injury.</p> <p>39176 73500</p>	<p>9</p> <p>▲ WARNING</p>  <p>BEWARE OF ENTANGLEMENT</p> <p>Keep your hands AWAY from moving parts such as V-belts, pulleys etc. Entanglement in them can cause serious injury.</p> <p>39176 73800</p>	<p>10</p>  <p>LIFTING BAIL</p> <p>39176 69300</p>

1.Safety


- The pasting position of safe warning label is as follows.



A090288


2.Part Names

2.1 Internal Components and Part Names



No.	Description	Function
1	Separator receiver tank	For separating compressor oil from compressed air sent into the tank.
2	Pressure control valve	For keeping the receiver tank pressure higher than 0.4MPa in the tank.
3	Safety valve	For releasing compressed air to the atmosphere when the pressure rises higher than the rated pressure.
4	Pressure regulator	For adjusting intake air volume (into compressor air-end)
5	Compressor oil filler port	For supplying and replenishing compressor oil.
6	Compressor oil filter	For filtering compressor oil circulating in the system.
7	By-pass valve	For keeping compressor oil at optimum temperature.
8	Air filter (For compressor)	For filtering the dust floating in the intake air.
9	Speed regulator	For regulating revolution speed of compressor air-end.
10	Fuel filter	For filtering dust and foreign matter mixed or to be mixed in the fuel oil.
11	Engine oil level gauge	For checking engine oil level.
12	Air filter (For engine)	For filtering the dust floating in the intake air.
13	Engine oil filter	For filtering engine oil.
14	Engine oil filler port	For supplying and replenishing engine oil to engine.
15	Fuel pre filter	For filtering dust and foreign things mixed in fuel oil and also for separating water.
16	Fuel filter (sedimenter built-in type)	For filtering dust and foreign matter mixed or to be mixed in the fuel oil and for separating water mixed or to be mixed in the fuel oil.
17	Reserve tank	For checking engine cooling water level and for replenishing cooling water.
18	Radiator	For cooling the coolant for engine because it is water-cooled.
19	Exhaust muffler	Equipment which muffles an engine exhaust sound.

2.Part Names




No.	Description	Function
20	Fuel tank drain valve	For draining condensate and water accumulated at the bottom of the fuel tank.
21	Fuel tank	For storing diesel fuel oil.
22	Coolant drain valve	For draining condensate from engine.
23	Compressor oil level gauge	For checking compressor oil level.
24	Compressor oil drain valve	For draining compressor oil from separator receiver tank.
25	Oil cooler	For cooling compressor oil circulating in the system.
26	Engine	For driving the compressor.
27	Air-end	For compressing intake air.
28	Solenoid valve (SV1)	For controlling starting unloader operation and purge operation.
29	Battery	For electrically starting engine.
30	Engine oil drain valve	For draining engine oil for replacement of it and for maintenance
31	Radiator drain valve	For draining condensate accumulated at the bottom of radiator.
32	Oil cooler drain valve	For draining condensate accumulated at the bottom of oil cooler.

2.Part Names

[After cooler type]

Only the special devise additionally or optionally attached to the standard unit are shown in the following figure. For the details of the other standard devices, refer to page 2-1,2-2.



No.	Description	Function
1	Drain separator	For separating water from compressed air cooled through oil cooler.
2	After cooler	For cooling compressed air.
3	Drain port of air pipe	For collecting condensate and draining it.
4	Drain warming valve	For preventing freezing of water separated through drain separator when exhausting it.

3. Installation

3.1 Transportation



WARNING

Transportation

- When loading and unloading unit, be sure to use the lifting bail provided on the center of the unit top.
- Never get under the unit which is lifted up, because it is very dangerous.
- When unit is transferred or moved from working site, be sure to place it on truck bed, and fasten it by ropes at the front eye and rear stand. (Trailer type)
- Put the chocks at both front and rear sides of the wheel tire without fail as shown in the figure. (Trailer type)
- Never lift unit which is still in operation, or it could cause critical damage to each component or lead to serious accident.


3.1.1 Lifting up

- ① Before lifting the unit up, make sure to check the lifting bail for any crack and loosened bolts.
- ② Connect the hook of the crane or shackle with lifting bail eye fitted at the top center of the unit, and make sure that there is no person standing around the unit. Then perform hoisting operation.
- ③ Select a truck or a crane with capacity sufficient for weight and size of the unit by referring to the values shown in Chapter 8 "Specifications" of the manual.

3.1.2 Mounting the unit on the truck bed


[Trailer type]

- Pass rope "1" through hooks "2" at front and rear sides as shown in the figure. And make sure to fasten the unit to truck bed with each rope "1" as shown in the figure.
- Never fasten the unit at the side of rear stand. Make sure to use the hooks "2" dedicated for fastening.
- Put the chocks "3" at both front and rear sides of the wheel tire without fail as shown in the figure.



[Box type]

- Pass the rope "1" through rope hook "2" as shown in the figure. And make sure to fix the unit on truck bed.
- In case of box type, be sure to put chocks "3" at the front and rear frames to the machine.




3. Installation

3.2 Towing the Unit

WARNING

- When towing unit, make sure there is no person or obstacle at both front and rear sides and under the unit.
Although the machine is designed to be drawn, drawing is allowed only in construction site.
- Towing speed should be within 20 km/h.
- When drawing the compressor, make sure to retract the castor. Drawing the compressor with the castor not retracted, and drawing it using the castor can lead to serious accidents or damaged to the castor.




CAUTION



Caution for towing unit

- Be sure to use a vehicle with enough capacity to tow the unit in operating weight.
- Standard pressure for a tire is at 0.45MPa.
- Be sure not to use wrong size or type of tire in changing.
- Make sure that the end of the drawbar is so surely and firmly connected to the coupler of the towing vehicle that the disconnection may not occur while the unit is being towed.
- Make sure if there is no deform or damage on the drawing vehicle and the drawbar of the unit.
- Be sure to keep your hand or finger away from any part of the coupling device when coupling or uncoupling a drawing device to a draw bar.
- Be sure to drive the drawing vehicle safely, avoiding dangerous place or ground, if any.
- If you do not follow the above instructions, it could cause serious injury or big damage.
- When drawing the compressor, make sure to retract the castor. Drawing the compressor with the castor not retracted, and drawing it using the castor can lead to serious accidents or damaged to the castor.


Wrong drawing method



Correct drawing method



How to retract the castor




A090301

3.Installation

3.3 Installation

WARNING


- Exhaust gas from the engine is poisonous, and could cause death when inhaled.
Avoid using the machine in an insufficiently ventilated building or tunnel.
- Do not position the exhaust gas outlet in direction of a person or a house.



WARNING

- The machine has to be parked horizontally on a level place.
- In case the machine has to be parked on a slope, place it across grade so that the machine does not tend to roll downhill.
- Following grades on a slope for the machine are recommended:
Box type within 10° degrees
Trailer type within 15° degrees
- In case of trailer type, be sure to put one set of chocks "1" to the wheels.


Installation



- The machine should be operated in following conditions:
 - Ambient temperature -15°C to +40°C
 - Humidity Less than 90%
 - Altitude Lower than 1,500 m above sea level
- Install the machine in a place with good ventilation, lower temperature and with surroundings as dry as possible.
- If more than two machines are placed parallel in operation, keep enough distance so that exhaust air from one machine does not effect the other one.
- Also, a machine has to be installed in the environment where fresh air is always available.
- Keep enough space around the unit for inspection and maintenance access.

4. Operation

4.1 Instrument Panel



1. Digital monitor indicator
(temp. /pressure/ rate of suction press.)
2. Selector switch for digital monitor indication
3. Discharge air pressure
(for pressure in separator receiver tank)
4. Fuel level gauge
5. Hour meter
6. Tachometer (option to be arranged at factory)
7. Starter switch

<Indicator lamp>

8. Glow

<Warning lamp>

9. Engine air filter clogging
10. Compressor air filter clogging
11. Charge
12. Low fuel level


<Emergency stop lamp>

13. Engine oil pressure
14. Water temperature
15. Discharge air temperature


4. Operation

4.1.1 Digital monitor indicator

- Place starter switch "RUN" and then digital monitor indicator goes on.
- Press monitor selector switch for selection of digital monitor display.



A090268E



4. Operation

4.1.2 Indicator lamp

Indicator lamp

Turn the starter switch to "RUN" position. Then the lamp goes on.

Item	Contents	Measures	Monitor
GLOW	Press starter switch "GLOW" and the lamp goes on and after preheating is finished, the lamp will be off.	—	

Warning lamp

When some little trouble occurs during operation, the lamps will flickers.

When the warning lamp flickers, take appropriate measures to recover the situation swiftly.

Item	Contents	Measures	Monitor
DISCHARGE TEMP.	Lamp flickers when the air temperature at the outlet of the air-end reaches the set temperature of 115°C.	Check wiring. Check alternator.	
WATER TEMP.	Lamp flickers when coolant temperature reaches 107°C.		
CHARGE	Lamp flickers when alternator is not charging.	Check wiring. Check alternator.	
COMP. AIR FILTER	Lamp flickers when air filter gets clogged and suction resistance increases. [Actuating resistance is more than 6.2kPa.]	Clean Replace	
ENG. AIR FILTER			
LOW FUEL LEVEL	Lamp goes on when fuel level in fuel tank becomes lower and it drops less than about 9L.	See "Troubleshooting"	

Emergency stop lamp

The compressor stops when the emergency stop lamp goes on.

Be sure to follow the measures shown below before starting the unit again.

Item	Contents	Measures	Monitor
DISCHARGE TEMP.	Lamp goes on when the air temperature at the outlet of the air-end reaches the set temperature of 120°C.	See "Troubleshooting"	
WATER TEMP.	Lamp goes on when coolant temperature reaches 110°C.		
ENG. OIL PRESS.	Lamp goes on when engine oil pressure drops. [The function pressure is below 0.05MPa.]		

4. Operation

4.2 Lubricating oil · Coolant · Fuel

4.2.1 Engine oil

IMPORTANT

- Viscosity of engine oil greatly affects startability, performance, oil consumption of the engine, as well as wear of the moving parts.
- Choose appropriate oil based upon the table below according to the outside air temperature.

Relation between viscosity (SAE) and temperature

SAE Viscosity number	Temperature
10W	− 30°C to 10°C
30	− 10°C to 40°C
40	0°C to 50°C
15W/40	− 20°C to 40°C

- Be sure to use CD class engine oil or superior class. (Using engine oil with poor quality may shorten the life of the engine).
- Follow the designated regulations to dispose of engine oil.

*** Unit is delivered ex. factory, filled with engine oil recommended by engine manufacturer.**

4.2.2 Compressor oil

IMPORTANT

Do not mix compressor oil

- Be sure to use recommended oil listed below.

Maker and Brand of Recommended Oil

Maker	Brand
MOBIL	MOBIL RARUS 424
SHELL	SHELL CORENA OIL RS32
CALTEX	COMPRESSOR OIL RA32

- Even continuous oil replenishment cannot improve its deteriorated condition. Be sure to change the oil completely at every scheduled interval.
- Do not mix it with other brand oil, or it will cause poor performance and shorten the life of the compressor oil. (But fresh compressor oil could accept a mixture of small amount of different brands.)
- Running the unit with old and deteriorated compressor oil will cause damage to bearings, or serious accident like ignition in a separator receiver tank. Be sure to change the oil completely at every scheduled interval.
- Follow the designated regulations to dispose of compressor oil.

4. Operation

4.2.3 Coolant

IMPORTANT

Quality of coolant and antifreeze

- Use soft water of good quality such as tap water for coolant.
- When water with dirt, sand, and/or dust contained, or hard water such as well water (ground water) is used, this will cause deposits inside radiator or on cylinder head, and will cause engine overheat due to poor flow of coolant.
- When the unit is used in a cold region and possible freezing is expected, it is recommended to use LLC (Antifreeze) for the coolant.
- Adjust mixing ratio of LLC (Antifreeze) with water according to the temperature.
- Use LLC (Antifreeze) within the range of its mixing ratio between 30 and 60%.
- If LLC (Antifreeze) in the water exceeds more than 60%, it may decrease its antifreezing effect. (Upon delivery from the works, LLC density is 35%)
- Follow the designated regulations to dispose of LLC (Antifreeze).

4.2.4 Fuel

IMPORTANT

Choose appropriate

- Be sure to use diesel fuel oil. (Using other oil will cause low power output or damage the engine.)
- As for fuel, use diesel fuel oil (having higher than 45 cetane number).
- Use of diesel fuel oil having lower than 45 cetane number will cause inferior function to engine and, what is worse, it will cause serious accident to the engine.

4. Operation

4.3 Check before starting unit



CAUTION

Check before starting unit


- Be sure to check the unit before operation.
When any abnormality is found, be sure to repair it before restarting the unit.
- Be sure to make daily checks before operation. If the unit is operated without prior check and without noticing its abnormality, such operation could cause seizure of components or may even cause fire.

4.3.1 Check engine oil level

- Unit should be on level before checking oil level.
- When you check oil level after you have once started operation, wait 10 to 20 minutes after stopping engine, before checking the oil level.

<Procedure>

- ① Pull out the oil level gauge "1", and wipe it with a clean cloth.
- ② Then, re-insert the oil level gauge "1" fully and pull it out again. If the oil level gauge "1" shows the oil level between LOW and HIGH, it is normal.
- ③ When the oil level is below its LOW, add engine oil from oil filler port "2".
- While checking oil level, check also for contamination. If the oil is found dirty, contaminated or should it be changed according to the periodic inspection list, change the oil. (See 5.6.1)
- Never fill oil more than HIGH level.




4. Operation

4.3.2 Check coolant level

CAUTION


- Be sure to stop the machine and allow time to cool. Then loosen the radiator cap one notch. After the coolant water is sufficiently cooled and the inner pressure is released, take the cap off.
If this procedure is neglected, the inner pressure can blow off the cap. Steam jetting out of the radiator could result in causing scalding. Follow this procedure under all circumstances.

Taking off the radiator cap



IMPORTANT

- Do not continue operation at low coolant level. Air bubble is mixed into radiator, and it causes damage to the radiator.
- Check the coolant level in the reserve tank. If it is lower than the limit, open the cap and replenish the coolant. (Level must be kept above LOW mark.)
- When there is a little water or no water in the reserve tank, remove the radiator cap and make sure to check the water level. Then supply coolant to the radiator and also the tank, if necessary. (See 5.6.17)




4.3.3 Check compressor oil level


WARNING

- When you refill the separator receiver tank with compressor oil, stop the engine, and make sure that the pressure gauge indicates 0MPa and there is no residual pressure in it, and then gradually loosen the oil filler cap for refilling oil.
- Should any residual pressure be left in the separator receiver tank, hot compressed air and hot compressor oil jetting out could cause burning or serious injury to persons nearby.

Refilling of compressor oil



- Place the machine on level ground when checking the oil level.
- Make sure to confirm that the level of compressor oil shall be higher than the lower limit of the plate "stopping". If not, replenish oil. (See 5.6.5)



4. Operation


4.3.4 Drain separator receiver tank




WARNING

Draining of Separator receiver tank

- After stopping the engine, confirm that the pressure gauge indicates 0MPa and there is no residual pressure in it, then open the drain valve gradually to drain the compressor oil.
- Note residual pressure in the receiver tank could force both extremely hot compressed air and oil to jet out and you may be scalded or seriously injured.



- Gradually opening the drain valve “2” fitted under the separator receiver tank “1” as shown in the fig, drain the condensate.
- Be careful not to fully open the drain valve “2” . Otherwise, much oil may be lost.
- After draining the oil completely, close the drain valve “2” firmly.
- Drain the condensate in container “3” , and then dispose of condensate according to the designated regulations.



4.3.5 Check fuel

- Before starting operation, make sure to check the level of residual fuel so that fuel shortage during operation can be avoided.
- Drain condensate accumulated at the bottom of fuel tank whenever necessary.



CAUTION

Fire prevention


- Do not, under any circumstance, bring lit cigarettes and/or matches to the fuel.
- The fuel is extremely flammable and dangerous. Be careful of fire because it is very likely to catch fire.
- Refuel only after stopping the engine, and never leave open fuel can near the machine. Do not spill. It could cause a fire. When it is spilt, wipe it up completely.
- Refilling fuel tank should be done in an outdoor well-ventilated place.
- Do not fill fuel oil up to the cap lever. When fuel tank is filled up to the cap level, fuel oil will be overfilled due to volume expansion caused by rise of ambient temperature. Further, fuel will be possibly spilled from fuel tank due to vibration caused during movement and/or transportation of machine.



4.Operation

4.3.6 Drain fuel tank

- Opening the drain valve “2” fitted under the fuel tank “1”, drain the condensate from the tank.
- When completely drained, firmly close the drain valve “2” .
- Drain the condensate in container “3”, and then dispose of condensate according to the designated regulations.




4.3.7 Check fuel filter for condensate in the filter (sedimenter built-in type)

When red float “2” under element “1” in fuel filter is raised up to upper level, drain water.

<Draining procedure>

- ① Turn fuel selector valve “3” to “OFF” position.
 - ② Loosen the drain valve “4” and drain out condensed water inside.
 - ③ Make sure to tighten the drain valve “4” securely, after draining the condensate.
- Drain the condensate in container, and then dispose of condensate according to the designated regulations.



4.3.8 Check wiring of each part

Check each wiring for any loose connection, damage to insulating sheathed portion, disconnection, and short-circuit.

4.3.9 Check piping of each part

Check each piping for any loose connection and also check each hose and pipe for any tear and leaks.

4. Operation

4.3.10 Check V-belt tension


IMPORTANT

- Too tight belt tension could damage shaft and shorten bearing life. Too loose belt tension may result in damaging belt earlier and machine components due to overheat.

Follow the procedure below to adjust tension of fan belt and V-belt for alternator.

<Procedure>

- ① Adjust the tension by gradually loosening the fastening bolt of the alternator.
- ② Visually check if there are any cracks or tears in the belt.
- ③ Adjust the belt tension by loosening the fixing bolt of the alternator so that the belt can deflect 10 to 14mm when pressed at the center of the belt with approx. 98N·m (10kgf·m) force.
- ④ Be careful not to leave any grease or LLC on a belt while changing it. If any such material is left, wipe it off completely.




4.4 Operation

CAUTION

Operation with compressed air supply port opened is prohibited

- Do not operate the machine with service valves and relief valve open unless air hoses and/or pipes are connected. High-pressurized air blows out and its air pressure could cause injury to the people nearby.
- When the machine has to be unavoidably temporarily operated with its port open, be sure to mount a silencer to reduce noise and wear protective materials such as earplugs to prevent damage to hearing.



WARNING

- Keep the door closed and locked while running the unit.
- When the door has to be opened, be careful not to touch portions that are rotating or very hot. Careless touch may cause serious injury.
- Pull the handle forward to open the door.
- Be sure to close the door tightly so that its latch is firmly caught.



4. Operation

4.4.1 Procedure to start the unit


IMPORTANT

Be sure to warm-up

- Be sure to let unit warm-up after starting for smooth operation of the engine and the compressor. Do not operate the engine at full load immediately after it starts up. This will shorten the equipment life.
- During the warm-up operation, examine the different parts of the equipment for any looseness, leakage of water, oil, fuel, and other irregularities.
- Also, make sure that monitor lamps are off.

<Procedure>

- ① Close fully service valve "1" .
- ② Keep starter switch "2" turned to "GLOW" position, then glow lamp "3" goes on. (Preheating time is about 15 seconds.)
- ③ As soon as the glow lamp "3" has gone out, turn the starter switch "2" fully clockwise to start up the engine.
- ④ Once the engine has started up, leave it running to warm-up for 5 minutes.
- ⑤ After finishing warming up operation, open the service valve "1" provided at the outlet of compressed air and start service job.



A090216-1E

4. Operation

4.4.2 Operating procedures when engine fails to start up on first attempt

- When the engine fails to start up even after performing the startup procedures ① to ③, do not keep the starter running, but set the starter switch back to "STOP" and wait about 30 seconds. Then, repeat the startup procedure once again.
- If the repeated procedure does not allow the engine to run, the following causes are suspected. Therefore, check the following:
 - No fuel
 - Clogging of fuel filter
 - Discharge of battery (Low cranking speed)

4.4.3 How to start the unit at low temperature

IMPORTANT


Operation under Cold Weather Conditions below -5°C

- Use SAE10W-30 (CD class) for the engine oil.
- Use LLC (antifreeze). Use correct amount to provide freeze protection, according to the ambient temperature.
- Battery should always be kept fully charged.

When it is difficult to start engine in cold weather, take the following measures.

<Procedure>

- ① Fully close the service valve, and fully open the low temperature starting valve "1" which is provided at the top of separator receiver tank for starting under the conditions of low temperature.
- ② Perform normal starting operation first and gradually close the low temperature starting air valve "1", watching the rising engine speed.



4.Operation

4.4.4 Gauge Indication while operating

IMPORTANT

- Minimum discharge air pressure is 0.40MPa during load operation.
- Continuing equipment operation at a lower pressure than the above pressure may cause overheating, since it affects the separation of lubricating oil inside the oil separator and reduces the oil flow to the compressor air-end, resulting in temperature rise.
- Be sure to check at times to see if gauges or each component of the unit are properly working, or if there is any air-leak, oil-leak, water-leak or fuel-leak etc.
- During normal operation, each indication of instruments is shown in the table below. Refer to the table for daily checks.
- The above table gives standard values. They may vary slightly depending on the operating conditions and other factors.

Protection device	Emergency stop lamp			Warning lamp			
	Discharge temperature	Water temperature	Engine oil pressure	Charge	Compressor air filter	Engine air filter	Low fuel level
Monitor							
Starting	Starter switch set to "RUN" position	● OFF	● OFF	● ON	● OFF	● OFF	● OFF
In Operation	— ● — OFF						

Protection device	Indicator lamp
	Glow
Monitor	
Starting	Starter switch set to "RUN" position
	※1 ● OFF
In Operation	— ● — OFF

Note)※1 : Lamp goes off after preheating completed.

		Discharge pressure gauge
In operation	Full load	0.4 to 0.69 MPa
	Unload	0.80 to 0.9 MPa

4.Operation


4.4.5 Performance check of safety valve

WARNING

- Keep face or hand away from the discharging outlet of safety valve. It is very dangerous because high-pressure compressed air jets out.

IMPORTANT

- Be sure to check the safety valve "1" performance once a day.
- Close the service valve completely and pull the test ring "2" of the safety valve "1" to check the performance. It is performing normally when the compressed air jets out with slight force at a discharge pressure between 0.7 to 0.9MPa. Wear safety glasses.
- Pressure setting for safety valve is 1.0MPa.



4.5 Stopping

<Procedure>

- ① Close the service valve completely and operate the machine about 5 minutes, until it cools down.
 - ② Turn the starter switch to "STOP" position to stop the engine.
 - ③ Remove the key from the compressor every time when you stop the engine. Keep the key and be careful not to lose it.
- Unless all the service valves are fully closed upon stopping operation, the compressed air will be sent in reverse direction in the hoses (pipes) connected to air tools and relieved to atmosphere continuously through the auto-relief valve. Further, when re-starting operation next time, compressed air will be jetted out through air valves.

4.Operation

4.6 Operation of after cooler type

The after cooler type compressor is capable of supplying low temperature compressed air.

4.6.1 Draining air pipe

- The condensate drained contains oily things. So dispose of the condensate, paying careful attention to it.
- In case that water is found mixed in the discharge air, make sure to check whether air is being discharged from air drain pipe during operation. (Carry out the following works after stopping the operation and confirming that there is no residual pressure.)


① When the air is not being discharged

It is possibly owing to the clogging of the silencer "1". Dismantle the silencer "1" after removing the rubber cover "2", and then clean the inside of the silencer "1". When it is impossible to get rid of the clogging, replace it by a new one.

② When air is being discharged

The possible cause is due to the clogging with dust between the pipes and nipples of the drain separator cup "3" and the silencer "1". So remove the drain separator cup "3", the pipe and nipple "4".

If water is still found mixed even after ①,② clause has been carried out, contact your nearest distributor or our company.



4.6.2 Drain warmer valve


- This valve "5" is provided to prevent condensate water from getting frozen when draining water separated. Run the unit with the valve being open when ambient temperature is lower than 5°C. But when freezing is impossible, the unit can be operated more efficiently if the valve is closed.

4. Operation

4.7 Volumetric Control System

FAC-75P, 75B

	Functions of solenoid valve (SV1)	Air flow
Start	OPEN	→
Load operation	CLOSE	→
Unload operation	CLOSE	→
Stop	CLOSE	→




A090270E

4.Operation

FAC-75PC, 75BC (After cooler type)

	Functions of solenoid valve (SV1)	Air flow
Start	OPEN	→
Load operation	CLOSE	→
Unload operation	CLOSE	→
Stop	CLOSE	→



A090271E

4.Operation

Step	Response
Start	When starting operation, solenoid valve (SV1) opens. And compressed air is sent to unloader chamber (A) and speed regulator chamber (B). The pressure in chamber (A) rises soon, and unloader valve fully closes due to low pressure. Thus the load required for starting is reduced.
Load operation	After starting operation, SV1 valve closes after 10 seconds have passed. The air volume sent to the chambers (A) and (B) from pressure regulator increases or decreases according to the rise and drop of discharge air pressure. Thus according as unloader valve position and engine speed change, free air delivery is steplessly and automatically regulated from 0 to 100%.
Suction port closing unload operation	When air consumption is reduced, and the pressure exceeds the rated one, speed regulator functions to lower the engine speed in proportion to the pressure rise and, at the same time, to close unloader valve. Under unloaded operation, the interior of compressor air-end becomes vacuum and vacuum noise is caused. In order to prevent occurrence of vacuum noise, it functions to open the vacuum relief valve, detecting the secondary pressure of pressure regulator and thus it prevents high vacuum state inside the compressor air end from being caused.
Stop	When stopping operation, it opens Auto relief valve to relieve the compressed air in separator receiver tank to atmosphere, detecting the pressure inside compressor air-end.

5.Periodic Inspection/Maintenance


5.1 Important Items at Periodic Inspection and Maintenance or after Maintenance

The following table shows the inspection and maintenance intervals under normal operation conditions. When used or operated under hard environmental conditions, it is impossible to warrant the unit even if the above conditions are performed according to the intervals listed in the above table.

WARNING

Hang a "Now Checking and under Maintenance" tag


- Remove the starter key from the starter switch before starting inspection, and hang up a "Now Checking and under Maintenance" tag where it can be easily seen. The checker must keep the key during checking and maintenance.
- Remove the negative (-) side cable from the battery. If the above procedure is neglected, and another person starts operating the machine during check or maintenance, it could cause serious injury.
- Use tools appropriate for the inspection and maintenance. Any makeshift or improper tools could cause unexpectedly injury by their slippage.



CAUTION

Prevention of oil separator from catching fire

- Be sure to perform oil change basically according to the specified interval. But if such oil is found much more contaminated before the interval, change the oil even before the specified period comes. In doing so, replace the oil completely and use our recommended oil.
- Be sure to perform following periodic inspection and maintenance:
 1. Check and change compressor oil
 2. Change oil separator
- Never mix the oil of different brands, or the mixed oil may deteriorate the oil quality.



5.Periodic Inspection/Maintenance

IMPORTANT


Directions: Prohibition of any other jobs or works than directed herein

- Be sure to use recommended fuel, oil, grease, and antifreeze.
- Do not disassemble or adjust engine, compressor or part(s) for which inspection or maintenance is not referred to in this manual.
- Use genuine parts for replacement.
- Any breakdown, caused by using unapproved parts or by wrong handling, will be out of the scope of "WARRANTY".
- Keep the electrical components away from water or steam.
- Waste from machines contains harmful material. Do not dispose of such harmful fluids to the ground, rivers, lakes or ponds, and sea. It contaminates the environment.
- When draining waste fluid from machines, use leakproof containers to hold such fluids from machine.
- Be sure to follow the designated regulations when disposing of oil, fuel, coolant, filters, battery and other harmful things.

5.2 Daily Inspection and Operation Log

- Be sure to carry out daily inspection every morning before operation. See Chapter 4 "Operation" of the manual for the details of inspection.
- Pay attention to and carefully observe the following points during daily operation or inspection and maintenance work. If any trouble or abnormality is found, immediately investigate its cause and make repairs. If the cause is unknown or not traceable, or if the trouble involves a part or component not described in the manual, ask your nearest dealer for information.

- (a) Controls and instruments function properly.
- (b) Quantity and any leak of water, fuel, and oil or any contamination should be checked.
- (c) Appearance, abnormal noise or excessive heat should be checked.
- (d) Loose bolt or nut should be checked.
- (e) Any damage, wear or shortage of machine components and parts should be checked.
- (f) Performance of each part or component should be proper.



- Keep the operation log to record constant inspection of each component, so that trouble of the unit can be easily discovered and preventive measures can be taken.
It is very useful to record information such as discharge pressure, oil level, as well as running hour, maintenance items and replenishment of lubricant on a daily maintenance log.

5.3 Inspection on Separator Receiver Tank

IMPORTANT

Periodic inspection of separator receiver tank

- Be sure to carry out the following cleaning and inspection of the separator receiver tank at least once every year.
<Procedure>
 - (1) Any damage found on the tank.
 - (2) Any excessive wear found to fastening bolts on the cover.
 - (3) Any damage found to pipes and valves etc.

5.Periodic Inspection/Maintenance

5.4 Periodic Inspection List

(Unit:Hour)

Maintenance	Daily	Every 250	Every 300	Every 500	Every 1,000	Every 2,000	Every 3,000	Every 8,000	Page
Check compressor oil level.	○								4-7
Drain separator receiver tank.	○								4-8
Check looseness in pipe connecting part, and wear and tear of pipe.	○								4-9
Check oil, water, fuel and air leak.	○								4-13
Check functions of all instruments and devices.	○								4-13
Performance check of safety valve.	○								4-14
Change compressor oil.			○ First time	○					5-8
Change compressor oil filter.			○ First time	○					5-9
Clean strainer in the scavenging orifice.				○					5-9
Clean and change air filter element.		○ (Clean)		○ (Change)					5-7
Clean outside of the oil cooler.					○				5-12
Clean outside of the after cooler. (After cooler type)					○				5-12
Check and clean of the silencer fitted at the drain port of air pipe. (After cooler type)					○				5-9
Supply grease to trailer spring pin.					○				5-12
Change speed regulator diaphragm.					☆●				5-12
Change oil separator.						●			5-14
Change nylon tubes.						●			5-14
Change unloader of o-ring.							★●		5-15
Change spacer of unloader.					※1○		★●		
Change pressure regulator.							●		5-14
Check hoses.							★●		5-15
Check o-ring and needle valve of auto-relief valve/ vacuum relief valve.							★●		5-15
Performance check of pressure control valve							●		5-16
Check and change gasket, o-ring and piston of pressure control valve.							★●		5-16
Check solenoid valve. (In case no abnormality is found, it can be used again.)							●		
Change oil seal and bearing.								●	

Such items marked ○ shall be carried out by customers.

For the following items or clauses marked ●, contact us directly or our distributors because they require expert technical knowledge on them.

Regarding the item marked ※1, check the function of the unloader. In case the unloader malfunctions, change O-ring or bushing of unloader. This is because either of both parts may be worn out.

The items or parts marked ☆ should be replaced every 2 years even if they are not in disorder within their periodical maintenance interval because their materials will change or become degraded as time passes.

Also for the same reason, the parts marked ★ should be replaced every 3 years.

5.Periodic Inspection/Maintenance

◎Refer to engine operation manual for inspection and maintenance of an engine.

(Unit:Hour)

Maintenance		Daily	Every 50	Every 250	Every 500	Every 1,000	Every 2,000	Every 3,000	Every 8,000	Page
Engine	Drain fuel tank	○								4-9
	Check fuel filter for condensate in the filter (sedimenter built-in type)	○								4-9
	Check fuel.	○								4-8
	Check engine oil level.	○								4-6
	Check coolant level.	○								4-7
	Check looseness in pipe connectors, terminals and tear in wiring.	○								4-9
	Check V-belt tension.	○								4-10
	Change engine oil.		○ First time	○						5-6
	Change engine oil filter.		○ First time	○						5-6
	Check battery electrolyte.			○						5-7
	Clean and change air filter element.			○ (Clean)	○ (Change)					5-7
	Change fuel filter.				○					5-10
	Change of element inside fuel pre-filter.				○					5-11
	Change of element in fuel filter. (sedimenter built-in type)				○					5-11
	Change coolant.					☆○				5-13
	Clean outside of radiator.					○				5-12
	Clean inside of radiator.					●				5-12
	Change fuel hose.						★●			5-14
	Clean inside of fuel tank.						●			5-14
	Change radiator hoses.							★●		5-16
Change wiring harness.								●		

The items or parts marked ☆ should be replaced every 2 years even if they are not in disorder within their periodical maintenance interval because their materials will change or become degraded as time passes. Also for the same reason, the parts marked ★ should be replaced every 3 years.

5.Periodic Inspection/Maintenance

5.5 Periodic Replacement of Parts

- Part number changes upon modification. For replacement of parts, make sure whether the part number is correct or applicable.

Part Name		Part Number	Quantity
Engine oil filter		YANMAR 119005-35160	1
Air filter element	For compressor	32143 12700 (outer cyl.)	1
		32143 12600 (inner cyl.)	1
	For engine	32143 12700 (outer cyl.)	1
		32143 12600 (inner cyl.)	1
Compressor oil filter		37438 05601	1
Fuel filter element		YANMAR 129907-55801	1
Element in fuel pre-filter	Element "3"	YANMAR 41650-550800	1
	O-ring "4"	YANMAR 123325-36140	1
	O-ring "5"	YANMAR 24311-000120	1
Element in fuel filter. (sedimenter built-in type)	Element	YANMAR 119802-55710	1
	O-ring (For element)	YANMAR 24311-000160	1
	O-ring (For body)	YANMAR 24321-000650	1
Unloader valve	O-ring "1"	03402 10125	1
	O-ring "2"	21441 03700	1
Oil separator	Separator "1"	34220 14900	1
	Gasket "2"	03737 29303	1
	Gasket "3"	03737 24810	1
Diaphragm for speed regulator		36437 01500	1
Pressure regulator		36400 19000	1
Auto-relief valve & vacuum relief valve	O-ring "1"	03402 02100	2
	O-ring "2"	03402 25021	2
	O-ring "3"	03402 25008	2
	Needle valve "4"	36429 00801	2
Pressure control valve	Gasket "5"	03737 11203	1
	Spring "6"	22144 07700	1
	O-ring "7"	03402 25032	1
	Piston "8"	35303 03300	1
Solenoid valve (SV1)	For starting unloader	46811 24100	1

5.Periodic Inspection/Maintenance

5.6 Maintenance Items

5.6.1 Change engine oil

[At 50 hours for the first change and at every 250 hours thereafter]



Caution in filling or discharging engine oil


- After stopping the engine, wait for 10 to 20 minutes until the engine oil cools off. Then check the level of the engine oil, or refill or drain the oil.
- Engine oil is very hot and highly pressurized during or just after the operation. Hot oil could blow out of the tank and can cause scalding.



W005

<Procedure>

- ① Remove the drain plug "1" attached outside the plane, open a drain valve "2" inside the plane, and discharge engine oil drain.
- ② When the oil is completely drained, close the drain plug "1" and drain valve "2" firmly and refill new engine oil through the engine oil filler "3" . [Quantity of oil : approx.10L]
- ③ After supplying oil, pull out the oil level gauge "4" and wipe it out.
- ④ Then, re-insert the oil level gauge "4" fully and pull it out again. If the dipstick shows the oil level between upper limit and lower limit, it is normal.




A090222

Oil level gauge

When oil level is within this zone, it is normal.

Upper limit

Lower limit




A090223E

5.6.2 Change engine oil filter

[At 50 hours for the first change and at every 250 hours thereafter]

<Procedure>

- ① Remove the cartridge "5" , using a filter wrench.
- ② Install the new cartridge after applying oil to the surface of gasket "6" of cartridge "5" . (For part number, see 5.5)
- ③ Give one turn to the cartridge "5" by hand after the packing touches the sealing face.
- ④ After installing the oil filter, check it for any leak during operation.



H000049

5.Periodic Inspection/Maintenance

5.6.3 Check battery electrolyte [Every 250 hours]

If there seems to be a problem in starting an engine due to a flat battery, carry out the checks by following the procedures below:

1. Ordinary type battery:

Check battery electrolyte level and if the level is not within the specified level, add distilled water.

Measure specific gravity of battery electrolyte, and if it shows below 1.24, recharge the battery immediately.

Refer to 6.1. for method of specific gravity measurement and recharging the battery.

2. Enclosed type battery:

Check the indicator on top surface of the battery.

If the indicator shows that charge is needed, recharge the battery immediately.

5.6.4 Check and clean air filter element [Every 250 hours]


IMPORTANT

Cleaning of Air Filter Element should be perfectly performed

- Clogged or cracked or pitted element could allow entrance of dust into engine and compressor to cause earlier wear of moving parts. Periodical inspection and cleaning of element should be performed to maintain life of compressor and engine long.

<Procedure>

- ① After removing the cap "1" by loosening its latch "2", clean its interior properly.
 - ② Take out outside shell "4" only, and clean it.
 - ③ Replace inside shell "3" once while outside shell is changed 4 times. Inside shell can not be used even if it is cleaned. In case inside shell "3" is removed, make sure to avoid entrance of dust and dirt.
 - ④ When installing the cap "1" after finishing the cleaning job, push the element into the case "5" surely by hand, and then make sure that the latch "2" fixing the cap surely hooks the case "5". Finally tighten it.
- If the element is found heavily dusty, replace it with a new one. (For part number, see 5.5)



5.Periodic Inspection/Maintenance


5.6.5 Change compressor oil

[At 300 hours for the first change and at every 500 hours thereafter]




Refilling of compressor oil

- When you refill the separator receiver tank with compressor oil, stop the engine, and make sure that the pressure gauge indicates 0MPa and there is no residual pressure in it, and then gradually loosen the oil filler cap for refilling oil.
- Note residual pressure in the receiver tank could force both extremely hot compressed air and oil to jet out and you may be scalded or seriously injured.
- Even continuous oil replenishment cannot improve its deteriorated condition. Be sure to change the oil completely at every scheduled interval.
- Do not mix it with other brand oil, or it will cause poor performance and shorten the life of the compressor oil. (But fresh compressor oil could accept a mixture of small amount of different brands.)
- Running the unit with old and deteriorated compressor oil will cause damage to bearings, or serious accident like ignition in a separator receiver tank. Be sure to change the oil completely at every scheduled interval.
- Follow the designated regulations to dispose of compressor oil.



<Procedure>

- ① Remove the oil filler cap "1" of separator receiver tank.
- ② Open drain valve "2" to discharge waste oil from the tank.
- ③ Completely discharge all the oil left separator receiver tank, pipes and oil cooler. If wasted oil is left in the unit, this residual oil will greatly shorten the life of the newly replenished oil.
- ④ Be sure to close drain valve "2" after the used oil is completely discharged.
- ⑤ Fill the designated quantity of new oil through the oil filler port. **[Quantity of oil : approx.30L]**
- ⑥ After oiling, tighten the cap "1" in its place while paying attention not to let dust get in the tank.
- ⑦ Start the engine for a short while, then replenish the oil to fill shortage. Repeat this procedure for 1 to 2 times to check if the oil level has reached its appropriate point. Be careful not to overfill the oil.



5.Periodic Inspection/Maintenance

5.6.6 Change compressor oil filter

[At 300 hours for the first change and every 500 hours thereafter]


IMPORTANT

Use our genuine oil filter

- Poor quality oil filters do not trap dust sufficiently and will cause damage to the bearings in a short period.

<Procedure>

- ① Remove the cartridge "1", using a filter wrench.
- ② Screw in the new cartridge "2" with the packing coated slightly with oil. (For part number, see 5.5)
- ③ After the packing touches the sealing face, further tighten it by turning it 3/4 time with the filter wrench.
- ④ After installing the oil filter, check it for any leak during operation.




5.6.7 Clean strainer in the scavenging orifice

[Every 500 hours]

<Procedure>

- ① Remove the pipe "3", using a spanner.
- ② First remove the bushing "4".
- ③ Then remove the strainer "5".
- ④ Wash the removed strainer "5" in diesel oil and blow out "dust" by air blowing.
- ⑤ After finishing the cleaning, install the strainer "5" again in the reverse procedure.



5.6.8 Check and clean of the silencer fitted at the drain port of air pipe

(After cooler type)

[Every 1,000 hours]

IMPORTANT

Make sure to clean silencer

- In case that no air is being discharged from the silencer, possibly silencer could be clogged. Periodically carry out inspection and cleaning of it.
- Regarding the details of the silencer, see 4.6.1 "Draining of air pipe".

5.Periodic Inspection/Maintenance

5.6.9 Change air filter element [Every 500 hours]


IMPORTANT

Use our genuine part

- Air filter is an important part which is crucial to machine's performance and life.
Be sure to use genuine parts.

<Procedure>



- ① After removing the cap "1" by loosening its latch "2", clean its interior properly.
 - ② Remove the element "3" "4" and then replace it with a new one. (For part number, see 5.5)
 - ③ When installing the cap "1" after finishing the replacing job, push the element into the case "5" surely by hand, and then make sure that the latch "2" fixing the cap surely hooks the case "5". Finally tighten it.
- When used or operated under bad conditions, it is better to remove all the elements, check them, clean them and replace them earlier before the intervals listed in maintenance table, if they are found difficult to be repaired.



5.6.10 Change fuel filter [Every 500 hours]

<Procedure>

- ① Remove the fuel filter cartridge "6", using a filter wrench.
- ② Install the new cartridge after applying oil to the surface of gasket "7" of cartridge "6".
(For part number, see 5.5)
- ③ Give 1 turn to the cartridge "6" by hand after the packing touches the sealing face.
- ④ After installing fuel filter cartridge "6", check for fuel leak during operation.




5.Periodic Inspection/Maintenance

5.6.11 Change of element inside fuel pre-filter [Every 500 hours]

<Procedure>


- ① Loosen drain plug "1" and drain oil.
- ② Remove center bolt "2" and take out element "3" .
- ③ Replace element "3" by new element, and replace O ring "4" or "5" if it is broken or damaged.
(For part number, see 5.5)
- ④ After finishing check and change, assemble it in reverse order.
- Drain the condensate in container, and then dispose of condensate according to the designated regulations.



5.6.12 Change of element in fuel filter (sedimenter built-in type) [Every 500 hours]

<Procedure>

- ① Turn the ring nut of cup "1" counterclockwise to remove the cup "1" . Be careful to remove the cup "1" because it is filled with fuel. Wipe out spilt fuel completely.
- ② Remove float "2" inside cup "1" .
- ③ Replace element "3" and O ring "4" if they are found broken or damaged.
(For part number, see 5.5)
- ④ After finishing check and change, assemble it in reverse order.
- If air is found still in fuel pipe, place starter switch to "RUN" position and loosen air bleeding bolt "5" to bleed air. After finishing air bleeding, tighten the air bleeding bolt "5" .
- Drain the condensate in container, and then dispose of condensate according to the designated regulations.




5.Periodic Inspection/Maintenance

5.6.13 Change diaphragm of speed regulator [Every 1,000 hours]


<Caution during diaphragm replacement>

- When installing diaphragm "1", be sure to use the special jig to prevent it from twisting.
- Before installing diaphragm "1", be sure to apply molybdenum disulfide (paste spray) to inside of the diaphragm "1".
- Install it so that its outside surface should be rubber and its inside cloth.
(For part number, see 5.5)
- When replacing it, contact directly us or distributor because it requires expert technical knowledge.



5.6.14 Clean outside of the radiator·oil cooler and after cooler [Every 1,000 hours]

- When the fin tubes "1" of a radiator, oil cooler and an after-cooler are clogged with dust or other foreign materials, the heat exchange efficiency drops and this will raise coolant temperature and discharge air temperature. These tubes and fins should be cleaned depending on the state of clogged tubes diaphragm "1", even before maintenance schedule.
- Do not use a high pressure washer to protect fin tubes "1" from being damaged.




5.6.15 Clean inside of radiator [Every 1,000 hours]

- When the inside of a radiator and water conduits of an engine are dirty with scale and rust, its cooling efficiency will be deteriorated. Clean the interiors of such components periodically.
- When cleaning it, contact directly us or distributor because it requires expert technical knowledge.

5.6.16 Supply grease to trailer spring pin [Every 1,000 hours]

- Supply grease through grease nipples positioned at the bottom.

Grease: Chassis grease



5.Periodic Inspection/Maintenance

5.6.17 Change coolant [1,000 hours or every 2 years]




Caution in filling or discharging engine oil

- Be sure to stop the machine and allow time to cool. Then loosen the radiator cap one notch. After the coolant water is sufficiently cooled and the inner pressure is released, take the cap off.
If this procedure is neglected, the inner pressure can blow off the cap. Steam jetting out of the radiator could result in causing scalding. Follow this procedure under all circumstances.
- LLC (Antifreeze) is a toxic material.
- When a person has drunk LLC (Antifreeze) by accident, make him vomit and see a doctor immediately.
- When a person gets LLC (Antifreeze) in his eyes, wash the eyes with clean running water and make him see a doctor immediately.
- When LLC (Antifreeze) is stored, put it in a container with an indication saying "LLC (Antifreeze) inside" and seal it up, then keep it in a place away from children.
- Beware of flames.



<Procedure>

- ① To drain coolant, first unfasten and take off the cap "1" of the radiator, then remove the drain plug "2" .
- ② Loosen the drain valve "3" provided on engine to drain engine.
- ③ When the drainage has been completed, fasten drain plug "2" drain valve "3" again and fill coolant into the radiator through its filler port. **[Quantity of water : approx.9.5L]**
- ④ After changing the coolant, operate the machine for 2 to 3 minutes at the unloaded condition and stop it. Then check the coolant level again, and replenish if it is short.




A070188

5.Periodic Inspection/Maintenance

5.6.18 Change oil separator [Every 2,000 hours]

- Even before the periodic interval time of replacement, replace the oil separator whenever the oil consumption increases and also oil is found mixed in the discharge air.
- When consumption of the oil is still unusual even after cleaning strainer in the scavenging orifice (See 5.6.7), change the oil separator "1" and gasket "2" "3" . (For part number, see 5.5)
- When replacing oil separator, contact directly us or distributor because it requires expert technical knowledge.



5.6.19 Change nylon tubes [Every 2,000 hours]

- Replace nylon tubes used for the oil and air pipings.
- When replacing it, contact directly us or distributor because it requires expert technical knowledge.

5.6.20 Clean inside of fuel tank [Every 2,000 hours]

- When cleaning it, contact directly us or distributor because it requires expert technical knowledge.

5.6.21 Change fuel hose [2,000 hours or every 3 years]

- In case various rubber hoses for fuel system and engine lubrication system are hardened or deteriorated, replace them even before the specified replacement time.
- When replacing hoses, contact directly us or distributor because it requires expert technical knowledge.

5.6.22 Change pressure regulator [Every 3,000 hours]

- Remove pressure regulator and rebuild or replace with a new unit. (For part number, see 5.5)

5.Periodic Inspection/Maintenance

5.6.23 Change o-ring of unloader [3,000 hours or every 3 years]

<Caution during O-ring replacement>

Supply grease to O-ring "1" , "2" after replacement. (For part number, see 5.5)

Grease: CALTEX MULTIFAX EP1

5.6.24 Check hose [3,000 hours or every 3 years]


- Check hoses used for oil piping for any crack or tear, and replace when an abnormality is found.
- When replacing hoses, contact directly us or distributor because it requires expert technical knowledge.

5.6.25 Check consumable parts of auto-relief valve and vacuum relief valve [3,000 hours or every 3 years]

IMPORTANT

- When reassembling, apply sufficient grease to O-ring Slot/O-ring and sliding surface.
Use CALTEX MULTIFAK EP1 grease or equivalent.

- Disassemble and clean the component, and check O-ring "1" , "2" , "3" and needle valve "4" . Then, replace O-ring "1" , "2" , "3" and rubber on the needle valve "4" , if hardened. (For part number, see 5.5)



5.Periodic Inspection/Maintenance


5.6.26 Performance check of pressure control valve [3,000 hours or every 3 years]

IMPORTANT

- When reassembling, apply sufficient grease to O-ring Slot/O-ring and sliding surface. Use CALTEX MULTIFAK EP1 grease or equivalent. Grease of poor quality will deteriorate the material.

<Procedure>

- ① When closing stop valve and fully opening service valve while the machine is running, make sure that the discharge pressure gauge shows the figure between 0.35 to 0.50MPa.
- ② When the pressure is lower than 0.35MPa, replace spring "6" with a new one. (For part number, see 5.5)
- ③ When the indicator shows excessively higher pressure, you will find that the piston does not move smoothly due to foreign material and rust stuck inside valve. In such a case, disassemble the component for checking and cleaning.



5.6.27 Check gasket, o-ring and piston of pressure control valve

- After disassembling and cleaning pressure control valve, check gasket "5, O ring "7" and piston "8". When the rubber of these parts is found hardened, or damaged, replace them. (For part number, see 5.5)
- When replacing it, contact directly us or distributor because it requires expert technical knowledge.
- After replacement, run the machine to check its function (See 5.6.26), air-leak or any disorder.

5.6.28 Change radiator hoses [3,000 hours or every 3 years]

- When any crack or wear is found on the hoses, change it even before the scheduled time.
- When replacing it, contact directly us or distributor because it requires expert technical knowledge.

6. Maintenance

6.1 Maintenance of Battery


WARNING

- Keep flames away from battery.
- Battery may generate hydrogen gas and may explode.
- Therefore, recharging should be done at a well-ventilated place.
- Do not spark near the battery nor light a match, nor bring lit cigarette and match close to the battery.
- Do not check the battery by short-circuiting the positive and negative terminals with a metallic piece.
- Never operate the machine nor charge the batteries with the battery liquid level being kept lower than the "LOWER" level. Continuing operation at this lower level will cause deterioration of such parts as pole plates etc., and also it may cause explosion as well as reduction of battery life. Add distilled water so that the liquid level may reach the middle level between the "UPPER" and "LOWER" level without any delay.
- Do not charge the frozen battery. Otherwise it may explode. If the battery is frozen, warm it up until the battery temperature becomes 16°C to 30°C.
- Battery electrolyte is dilute sulfuric acid. In case of mishandling, it could cause skin burning.
- When you deal with a battery, please be sure to wear protection implements, such as protection glasses and a glove.
- When such battery electrolyte contacts your clothes or skin, wash it away with large amount of water immediately.
- If the battery electrolyte gets into your eyes, wash it away immediately with plenty of water and see a doctor at once, because it is feared that eyesight might be lost.
- Dispose of battery, observing local regulations.

Handling battery



D004



W010




TR0093

6. Maintenance

6.1.1 Charge battery

- Be sure to read the operation manual of the battery charger to know if it is applicable, before using it.
- Disconnect the cable between battery and the unit, and charge the battery with a 12V battery charger. Do not charge two batteries at the same time.
- Be sure not to connect (+) and (-) terminals backwards.



6.1.2 How to use booster cable




Do not reverse the cable connection

- If a booster cable has to be used or when cables are connected at battery replacement, be careful not to connect (+) and (-) terminals backwards. Such a wrong-connection will cause spark and damage each component.

<Procedure for using a booster cable>

- ① Stop the engine.
- ② Connect one end of the (+) cable to the (+) terminal of the machine battery.
- ③ Connect the other end of the (+) cable to the (+) terminal of the external battery.
- ④ Connect one end of the (-) cable to the (-) terminal of the external battery.
- ⑤ Connect the other end of the (-) cable to the engine block of the machine.
- ⑥ Start up the engine.
- ⑦ Disconnect the booster cable by following the procedure back in the reverse order.



6. Maintenance

6.2 Troubleshooting

- Should any trouble occur during operation, do not leave it. Investigate the cause and take appropriate measures.
- Read the manual carefully and fully understand what to do in case of trouble.
- The better you understand the construction and function of the unit, the faster you can find a problem and solution.
- This chapter describes the state, cause and countermeasures of important troubles in detail:

Symptom	Cause	Countermeasures
Low starter revolution speed.	(1) Battery malfunction.	Check battery→ Charge, change
Starter rotates but engine does not start.	(1) Fuel filter clogging. (2) Malfunction of fuel cut solenoid. (3) No fuel.	Disassemble, clean, and change Check fuse Change solenoid Check connector Replenish fuel
Discharge air pressure does not reach 0.69MPa.	(1) Pressure regulator insufficient adjustment.	Re-adjust (fasten)
Engine does not reach its maximum speed.	(1) Improper length in speed regulator rod. (2) Unloader orifice clogging. (3) Malfunction speed regulator. (4) Engine trouble. (5) Fuel filter clogging.	Re-adjust Disassemble/Clean Disassemble/Check Call your nearest dealer Disassemble/Change
Revolution drops before discharge air pressure reaches 0.69MPa.	(1) Pressure regulator insufficient adjustment. (2) Trouble of pressure regulator. (3) Unloader orifice clogging.	Re-adjust (fasten) Change Disassemble/Check
Engine does not reach minimum revolution at unload.	(1) Improper length in speed regulator rod. (2) Malfunction speed regulator.	Re-adjust Disassemble/Check
Safety valve relieves at unload.	(1) Pressure regulator insufficient adjustment. (2) Speed regulator diaphragm damaged. (3) Unloader valve damaged. (4) Faulty safety valve. (5) Improper length of speed regulator rod	Re-adjust (loosen) Change Change Change Re-adjust (elongate)
Oil mixes in air. (poor oil separation)	(1) Scavenging orifice strainer clogging. (2) Excessive oil in tank. (3) Low discharge pressure. (4) Oil separator element deteriorated.	Disassemble/Clean Drain to its proper level Disassemble and check of pressure control valve Check /Change
Insufficient free air delivery.	(1) Air filter element clogging. (2) Unloader valve cannot fully open. (3) Engine does not reach rated speed.	Clean or change of element Call your nearest dealer Call your nearest dealer

6. Maintenance

Symptom	Cause	Countermeasures
Water found mixed in discharge air. (Condensate separation malfunctioned.)	(1) Element of drain separator clogged. (2) Silencer fitted at draining portion of air pipe clogged. (3) Inside of piping between after-cooler and silencer clogged with dust.	Disassemble/Clean/Change Disassemble/Clean/Change Disassemble/Clean
Engine oil pressure lamp goes on and engine stops.	(1) Engine oil shortage. (2) Engine oil filter clogging. (3) Faulty oil pressure switch. (4) Loosened or disconnected wiring or connector.	Replenish oil Change Change Check/Fasten
Water temperature lamp goes on and engine stops.	(1) Radiator clogging. (2) Faulty thermostat. (3) Faulty coolant temp. switch. (4) Low coolant level. (5) Fan belt slippage. (6) Loose wiring, connectors and disconnection.	Clean Change Change Replenish Re-adjust tension Check/retighten
Discharge air temperature lamp goes on and engine stops.	(1) Oil cooler clogging. (2) Oil filter clogging. (3) Faulty discharged air temp. switch. (4) Loose wiring connectors and disconnection. (5) Slippage of fan belt. (6) Shortage of compressor oil. (7) Malfunction of by-pass valve.	Clean Change Disassemble/Check Check/retighten Re-adjust tension Replenish oil Check/change
Low fuel level lamp goes on.	(1) Fuel runs short. (2) Malfunction of sending unit for fuel oil level drop. (3) Loosened and disconnected wiring connection and connectors.	Add fuel oil Check/change Check/retighten

- Contact your nearest dealer if you find it difficult to repair by yourselves.
- Refer to the engine operation manual for trouble concerning the engine.

7. Storage of the Unit

7.1 Preparation for Long-term Storage

When the unit is left unused or not operated longer than half a year (6 months), store it at the dry place where no dust exists after the following treatments have been done to it.

- Put the unit in a temporary cabin if it is stored outside. Avoid leaving the unit outside with a sheet cover directly on the paint for a long time, or this will cause rust to the unit.
- Perform the following treatments at least once every three months.

<Procedure>

- ① Drain existing lubricant from the engine oil pan. Pour new lubricant in the engine to clean its inside. After running it for a while, drain it again.
- ② Spread lubricant on moving parts like speed regulator and rod end, beforehand.
- ③ Completely charge the battery and disconnect grounding wires. Remove the battery from the unit, if possible, and store it in a dry place. (Charge the battery at least once every month.)
- ④ Drain coolant and fuel from the unit.
- ⑤ Seal the engine, air-intake port and other openings like the muffler with a vinyl sheet, packing tape, etc., to prevent moisture and dust from getting in the unit.
- ⑥ Be sure to repair any trouble and maintain the unit so that it will be ready for the next operation.

8. Specifications

8.1 Specifications


Model		FAC-75P <FAC-75PC>	FAC-75B <FAC-75BC>	
Compressor	Type	Single-stage oil cooled, screw type compressor		
	Free air delivery	m ³ /min	7.5	
	Working pressure	MPa	0.69	
	Lubricating system	Forced Lubrication by compressed pressure		
	Driving system	Direct driving with gear coupling		
	Receiver tank capacity	m ³	0.069	
	Lubricating oil capacity	L	30	
Engine	Model	YANMAR 4TNV98T-NHK		
	Type	4-cycle, water-cooled, direct injection type with turbo charged		
	Number of cylinders, bore stroke	4 - 98mm × 110 mm		
	Total displacement	L	3.319	
	Rated output	kW/min ⁻¹	61.2 / 2,500	
	Lubricating oil capacity	L	10.5 (The amount of initial filling)	
			10 (The amount of exchange)	
	Coolant capacity (including radiator)	L	10	
	Battery	95D31R (12V)		
	Fuel tank capacity	L	115	
Weight · Mass	Overall length (Bonnet only)	mm	2,050	2,050
	Overall length (with drawbar folded up)	mm	—	—
	Overall length (with drawbar laid down)	mm	2,980	—
	Overall width	mm	1,630	1,200
	Overall height	mm	1,715	1,250
	Net dry mass	kg	1,320 <1,340>	1,150 <1,180>
	Operating mass	kg	1,460 <1,480>	1,290 <1,320>

* The values in :< > shows those of the after cooler type.

8. Specifications

8.2 Outline drawing


FAC-75P
FAC-75PC (After cooler type)



A090287

8. Specifications


FAC-75B
FAC-75BC (After cooler type)



A090218E

9.Wiring Diagram

A090237E




Position of electrical apparatus provided on backside of instrument panel.

NO.	Part No.	Part Name
1	44346 16400	Safety relay
2	44327 05000	Solenoid relay
3	44346 08300	Heater lamp relay
4	44327 08100	Time relay (1S)
5	44327 08700	Time relay (1S)
6	48879 48700	Controller
7	46953 04200	Fuse folder (30A)
8	44327 08700	Fuse folder (5A)

	OFF	R1	DN	ST	B	R1	ACC	BR	C	R2
	○	○	○	○	○	○	○	○	○	○


Starter SW.



Note) The wire size without directions is 0.85mm².

10.Piping Diagram


FAC-75P, 75B



A090238E

10.Piping Diagram

FAC-75PC, 75BC (After cooler type)



A090239E

Copyright(C)2009 CURTIS-TOLEDO, INC. All Rights Reserved.

39600 04931
PRINTED DATE 2009.12

